

Notes	•
140103	•

- 1. All dimensions are in millimetres unless otherwise stated.
- 2. The foundation size is indicative only and will depend upon ground conditions, groundwater level and wind loadings.
- 3. Inserts and ducting to be supplied by turbine manufacturer.
- 4. Earthing details are indicative, subject to turbine supplier approval.
- 5. Suitable formation to be specified by turbine supplier.

